


ASSEMBLE DRAWING MX-5500 PLUS



Part No.	DESCRIPTION	Part No.	DESCRIPTION	Part No.	DESCRIPTION	Part No.	DESCRIPTION
A01	PRINT CASE COVER	C06	RAID WASHERS	B01	WASHER WASHER	G08	ATTACH ROLLER SHIRT
A02	LEFT SIDE COVER	C07	SELECT WASHERS	B02	PRINT ROLLER	G09	PRINT WASHERS SPES
A03	SHIRT	C08	FLAME OF SQUARE RING COVER	B03	PRINT ROLLER	G10	SPRING (MATHIUM) SPES
A04	PAPER SUPPORT (MATHIUM) SPES	C09	FLAME OF SQUARE RING (G07)	B04	PRINT WASHERS	G11	COVER
B01	WASHER	C10	FLAME OF SQUARE RING (MATHIUM)	B05	PRINT PLATE	B01	INK CASE COVER
B02	WASHER SPRING	C11	FLAME OF SQUARE RING SPRING SPES	B06	PRINT PLATE WASHERS	B02	INK CASE
B03	WASHER FEED ROLL	C12	SCREW RING	B07	PRINT PLATE PIN	B03	INK CASE
B04	FLAT WASHER (MATHIUM) SPES	C13	FLAME OF SQUARE RING PIN	B08	PLATE OPEN KEY	B04	INK ROLLER SHIRT
B05	SPRING (MATHIUM) SPES	C14	LETTER RING	B09	PLATE OPEN KEY SPRING	B05	INK ROLLER SHIRT COVER
C01	LETTER RIGHT CASE	C15	LETTER RING	B10	PRINT PLATE COVER	B06	SPRING ROLLER
C02	LETTER LEFT CASE	C16	LETTER CASE SHIRT	B11	PRINT PLATE COVER OPEN KEY	B07	INK
C03	BALL BEARING	C17	PAPER SCREW (MATHIUM)	B12	PRINT PLATE COVER OPEN KEY SPRING	B08	STRIPPER
C04	BALL BEARING SPRING	C18	PAPER SCREW (MATHIUM)	B13	WASHER WASHERS RING		
C05	WASHER SCREW SHIRT	D01	WASHER WASHERS RING	B14	WASHER WASHERS SPRING		
		D02	WASHER WASHERS SPRING	C07	WASHER WASHERS		
		D03	WASHER WASHERS SPRING				